



**NOTES:**

DETAIL TO ACCOMMODATE MAXIMUM OF 25% TOTAL MOVEMENT.

BACKER ROD SHOULD BE PLACED AT A DEPTH OF NO MORE THAN 1/2-INCH DEEP.

APPLY 2-PART URETHANE IN JOINT. LET CURE A MINIMUM OF 12 HOURS.

APPLY BOND BREAKER TAPE OVER SEALANT.

APPLY CIM TOPCOAT OVER TOP OF BOND BREAKER TAPE AND EXTEND BEYOND JOINT FACES A MINIMUM OF 2-INCHES.



**C.I.M. Industries Inc.**  
 23 Elm Street  
 Peterborough, NH 03458  
 www.cimindustries.com  
 603-924-9481

DATE  
 09.09.02

SCALE  
 NTS

**CIM 03-0019**

PROJECT:  
 C.I.M. INDUSTRIES INC.

TITLE: CIM 2000  
 EXPANSION JOINT DETAIL